



ANKER

SERIES 7




ANKER 737 POWER BANK  
(PowerCore 24K)  
QUICK START GUIDE

Charging Your Devices





Recharging Your Power Bank



Trickle-Charging Mode

Charge your accessories in trickle-charging mode.



For FAQs and more information, please visit:  
[anker.com/support](https://anker.com/support)



@anker\_official  
@anker\_jp




@Anker Deutschland  
@Anker Japan  
@Anker







@AnkerOfficial  
@Anker\_JP

Product Number: A1289 51005003422 V01

LCD Screen Guide



To exit trickle-charging mode.



Specifications  
製品の仕様

|  |   |
|--|---|
| Cell Capacity<br>セル容量                            | 24000mAh<br>(4000mAh*6pcs)                                    |
| USB-C 1 Input<br>USB-C 1 入力                      | 5V = 3A / 9V = 3A / 15V = 3A / 20V = 5A / 28V = 5A (140W Max) |
| USB-C 1 / USB-C 2 Output<br>USB-C 1 / USB-C 2 出力 | 5V = 3A / 9V = 3A / 15V = 3A / 20V = 5A / 28V = 5A (140W Max) |
| USB-A Output<br>USB-A 出力                         | 5V = 3A / 9V = 2A / 12V = 1.5A (18W Max)                      |
| Total Output<br>合計出力                             | 140W Max  |